

MAINTENANCE INSTRUCTION

PINLOCK® PROTECTINT™ OVERLAY

Your Pinlock® ProtectINT™ photochromic Overlay changes colour under the influence of UV light. The photochromic performance may vary depending on the intensity of the UV light, the UV intensity is for instance lower during a cloudy day.

To ensure the best performance of your Pinlock® ProtectINT™ photochromic Overlay, make sure it does not get too hot. High temperatures may lead to temporary loss of performance. Should the Overlay become too hot, for instance because your helmet has been kept in the boot of your car on a sunny day, allow it to cool down and regain functionality.

INSTALLATION PINLOCK® OVERLAY

1. Check if your helmet shield is fitted with tear-off buttons. (Fig. A) If this is not the case, please first continue with "INSTALLATION PINLOCK® TEAR-OFF BUTTONS".
2. Start by turning the tear-off buttons inwards. (Fig. B)
3. Position the Pinlock® Overlay on the outside surface of the helmet shield and align the holes with the tear-off buttons.
4. Firmly secure the Pinlock® Overlay onto the helmet shield by turning the Pinlock® tear-off buttons outwards.
5. Make sure that the Pinlock® Overlay remains firmly fixed by regularly checking that sufficient tension is applied to the lens by the tear-off buttons.

REMOVING

6. Turn the tear-off buttons inwards. (Fig. C)
7. Gently remove the Pinlock® Overlay from the tear-off buttons.

CLEANING

8. Remove the Pinlock® Overlay as explained in the paragraph "REMOVING"
9. Use only a clean cloth and lukewarm water to clean your Pinlock® Overlay. Avoid abrasive cloths, towels, paper towels and similar items that might cause damage.

DO NOT USE ABRASIVE CLEANING PRODUCTS OR LIQUIDS CONTAINING AMMONIA OR ALCOHOL.

INSTALLATION PINLOCK® TEAR-OFF BUTTONS

10. When there are no Pinlock® tear-off buttons mounted: remove the original pins from the helmet shield as in the helmet manufacturers instructions.
11. Place the male part in the hole on the inside of the helmet shield. (Fig. D)
12. Position the tear-off button onto the male part from the outside of the helmet shield and secure it by using the screw. (Fig E)
13. Make sure that the screw is not overtightened. The pin should be able to rotate using the Pinlock® Pintool (included in the box) from the outside. The tear-off button should be able to rotate, while the male part stays in position in case a Pinlock® lens is fitted on the inside of the helmet shield.

USING THE PINLOCK® PINTOOL

14. The Pinlock® Pintool can be separated by turning the two main parts a quarter turn in opposite directions.
15. The hexagon part fits over the male part on the inside of the helmet shield.
16. Use the screw part to tighten the screw on the out side of the helmet shield.

COMBINING THE PINLOCK® OVERLAY WITH THE PINLOCK® ANTIFOG INSERT

17. The Pinlock® Antifog insert can be used in combination with an Overlay. Check the Pinlock® Antifog insert packaging or the Pinlock® support page online for the correct fitment of the lens.

The Pinlock® Overlay is not intended for wet conditions as it is possible for moisture to creep between the Pinlock® Overlay and the helmet shield due to the enormous wind pressure that arises when riding. For this reason, we recommend that you remove your Pinlock® Overlay when it starts to rain. If moisture appears in the chamber between the helmet shield and the Pinlock® Overlay, please remove it from the helmet shield. Leave the Pinlock® Overlay and the helmet shield to dry properly before reassembling them.







LIMITED WARRANTY

Pinlock® warrants to the original owner that the Overlay will be free from defects in materials and workmanship for a period of one (1) year from the date of original purchase. Pinlock® shall, at its sole discretion, repair or replace any defective lens or refund the purchase price. Pinlock's warranty does not apply to any damage caused by abuse, misuse, neglect, alteration, normal wear-and-tear, improper installation or cleaning, or accident (including, without limitation, racing, performing stunts or similar activities). Pinlock's warranty does not apply to the Pinlock® prepared face shield or the position of the holes in the Pinlock® prepared face shield. This warranty and remedies are exclusive and in lieu of all other warranties and remedies, whether verbal or written, express or implied. No Pinlock® reseller, dealer, agent or employee is authorized to modify, extend or enlarge this warranty and remedies. In order to invoke the warranty, the original owner must deliver the lens to an authorized Pinlock® dealer, together with the bill of sale or other dated proof of purchase document.

PINLOCK® DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF PINLOCK® CANNOT LAWFULLY DISCLAIM OR EXCLUDE IMPLIED WARRANTIES UNDER APPLICABLE LAW, THEN TO THE EXTENT POSSIBLE, ANY CLAIMS UNDER SUCH IMPLIED WARRANTIES SHALL EXPIRE ON EXPIRATION OF THE ABOVE WARRANTY PERIOD. PINLOCK® IS NOT RESPONSIBLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY.

Pinlock® is subject to international patent conditions and is a registered trademark.

Various patents have been applied for.



FOR MORE INFORMATION ABOUT OVERLAY GO TO

 **PINLOCK.COM**